

www.rockymountainsnowguards.com

ST18 SNOW GUARD SYSTEM

AVAILABLE MATERIALS:

- COPPER
- PAINTED ALUMINUM

INFORMATION:

- Classic Low Profile Design
- Light gage metal strap allows for simple nail attachment on new roofs and exposed screw fastening on existing roofs.
- Pad area is 2.34 square inches
- Overall length is 18", Strap length is 15.75"
- Excellent Choice for:
 - New synthetic shingle roofs on lower pitches with lighter snow loads
 - New natural slate roofs with lighter snow loads
 - New tile roofs fastened directly to deck
 - New wood shingle and shake roofs

EXAMPLES:









FAX: (720) 387-8361


www.rockymountainsnowguards.com


ST18 SNOW GUARD

SELECT DESIRED MATERIAL:

☐ COPPER - 16 OZ


☐ PAINTED ALUMINUM - 0.032"







SIDE VIEW



MANUFACTURER NOTES:

- 1. ONTACT MANUFACTURER FOR SPECIFIED LAYOUT PATTERN.
- 2. F R CUSTOM MATERIALS CONTACT MANUFACTURER.
- 3. THER SIZES ARE AVAILABLE ON A CUSTOM BASIS.

NOTES:

- 1. I STALLATION TO BE COMPLETED IN ACCORDANCE WITH MANUFACTURER'S SPECIFICATIONS.
- 2. O NOT SCALE DRAWING.




www.rockymountainsnowguards.com

INSTALLATION INSTRUCTIONS

SNOW GUARD PLACEMENT FOR SHINGLE STYLE ROOFS (Asphalt Shingle, Tile, Slate, Synthetics, Metal Shingle)


Less than a 6/12 Pitch

For roofs less than 6/12 pitch, the distance between the butt end and the pad face must be a minimum of 3x the thickness of the roofing material.




Greater than or equal to 6/12 Pitch


For roofs greater than 6/12 pitch, the distance between the butt end and the pad face must be a minimum of 6x the thickness of the roofing material.




EXAMPLE PATTERNS: (Specified pattern and dimensions are dependent on individual roof characteristics.)




TRADITIONAL SPREAD PATTERN



MULTIPLE SOLDIER ROW



SOLDIER ROW WITH SPREAD PATTERN



SNOW FENCE WITH SOLDIER ROW




www.rockymountainsnowguards.com

INSTALLATION INSTRUCTIONS CONTINUED


NEW ROOF

- Follow recommended layout pattern for specific roof and snow situation following the Rocky Mountain Snow Guard Layout Guide.
- 2. Mark location of each snow guard.
- 3. Fasten snow guard with appropriate quantity and type of fasteners:
 - -ST / Yeti: Fasten through top 3" of strap. -RG: Fasten through fastening holes in strap.
- 4. Continue shingling roof.



EXISTING ROOF

- Follow recommended layout pattern for specific roof and snow situation following the Rocky Mountain Snow Guard Layout Guide.
- 2. Mark location of each snow guard and apply appropriate sealent to shingle where fasteners will penetrate.
- Attach with 2 or 3 Woodbinder Eclipse #10 screws:
 - -ST / Yeti: Fasten through exposed strap.
 - -RG: Fasten through fastening holes in strap.



ST18 Snow Guard Specification Sheet

For synthetic slate and shake, cedar shingles and shakes, slate and tile roof systems

PART 1 - GENERAL

1.1 SUMMARY

A. WORK INCLUDES

- 1. ST18 snow guard attaches directly to the roof deck.
- Coordinate with the installation of the roof to assure proper placement of the snow guards.
- 3. Provide appropriate snow guard and fasteners for the roof system

B. RELATED SECTIONS

1. Section 07600: Flashings and Sheet Metal

Section 07310: Shingles
Section 07320: Roofing Tiles

4. Division 7: Thermal and Moisture Protection

1.2 SYSTEM DESCRIPTION

A. COMPONENTS

- 1. ST18 snow guard system consists of individual metal snow guards
- 2. Fasteners
 - a. To be of metal compatible with snow guards
 - b. Fasteners should be selected for compatibility with roof deck
 - c. All snow guards must be mechanically fastened to the roof deck.
- 3. Sealant
 - a. To be approved by the roofing material manufacturer

B. DESIGN REQUIREMENTS

- 1. Spacing to be recommended by manufacturer or building engineer.
- 2. Minimum 2 fasteners per snow guard.
- 3. It is important to design new structures or assess existing structures to make sure that they can withstand retained snow loads.

1.3 SUBMITTAL

A. Submit manufacturer's specifications, standard detail drawings, recommended layout and installation instructions.

1.4 QUALITY ASSURANCE

A. Installer to be experienced in the installation of specified roofing material and snow guards for not less than 5 years in the area of the project.

1.5 DELIVERY / STORAGE / HANDLING

A. Inspect material upon delivery and order replacements for any missing or defective items. Keep material dry, covered and off the ground until installed.

PART 2 - PRODUCTS

MANUFACTURER

2.1 A. Rocky Mountain Snow Guards, Inc. 4231 S. Natches Court, Unit C, Englewood, CO 80110 (877) 414-7606 / www.rockymountainsnowguards.com

2.2 MATERIALS

- A. Copper all snow guard components are 16 oz. copper.
- B. Aluminum All snow guard components are .032 Aluminum

2.3 FINISH

- A. Mill Finish
- B. Kynar 500 pre finished sheet Aluminum only.
- C. Powder Coated, exterior grade powder only.

PART 3 - EXECUTION

3.1 EXAMINATION

- A. Substrate
 - Inspect structure to verify that roofing structure will withstand additional retained snow loads. Notify owner or general contractor of any deficiencies before installing snow guards.
 - 2. Verify that roofing material has been installed properly prior to installing snow guards.

3.2 INSTALLATION

A. Comply with architectural drawings for location and with Manufacturer's instructions for installation and layout.

07 72 53 Snow Guards

Rocky Mountain Snow Guards, Inc., 4231 S. Natches Court, Unit C, Englewood, CO 80110 (877) 414-7606 / www.rockymountainsnowguards.com



www.rockymountainsnowguards.com

Rocky Mountain Snow Guards Snow Retention System Maintenance Guide

Systems designed by Rocky Mountain Snow Guards, installed properly should last the life of the roof. Rocky Mountain does not recommend adhesive tape or sealant attachment for any snow fence or snow guard system. Rocky Mountain snow retention systems installed on commercial buildings, above high traffic areas or in areas with high snow loads should be inspected by a qualified roofing or snow retention professional on an annual basis to ensure the system will continue to perform as designed.

Bolt Down Snow Fence Systems:

- 1. Inspect brackets, snow fence components and fasteners for evidence of damage.
- 2. Replace damaged parts prior to the next snow season.

Clamp to Seam Snow Fence and Snow Bar Systems:

- 1. Inspect brackets, snow fence and snow bar components for evidence of damage.
- 2. Replace damaged parts prior to the next snow season.
- 3. Check torque on set screws with an appropriate torque wrench.
- 4. Torque set screws to recommended torque. This is especially important after the 1st snow season.

Snow Guards:

- 1. Inspect snow guards for evidence of damage.
- 2. Inspect exposed fasteners.
- 3. Replace damaged parts prior to the next snow season.