



Rocky Mountain
Snow Guards Inc

ROCKY MOUNTAIN SNOW GUARDS
4231 S. NATCHES COURT, UNIT C
ENGLEWOOD, CO 80110
PHONE: (877) 414-7606
FAX: (720) 387-8361
www.rockymountainsnowguards.com

Drift Corrugated Series Installation Instructions

- 1.** Locate and mark installation locations for Brackets in accordance with the layout pattern provided by Rocky Mountain Snow Guards. Generally, Drift snow fences are installed 12" above the eave edge. Additional rows of snow fences may be required above the eave row depending on specific job conditions. Drift Corrugated Brackets are to be fastened into solid wood blocking or into the roof support structure.
- 2.** Using a Drift Corrugated Bracket, mark locations for each of the 3 fasteners at each bracket location.
- 3.** Drill 5/16" holes through the corrugated panel where marked in step #2. Drill pilot holes into the decking and blocking for #15 x 2.5" CTX screws.
- 4.** Apply sealant on top of the corrugated panel around the holes drilled for lag bolts.
- 5.** Place brackets with bracket holes and corrugated panel holes aligned.
- 6.** Place and tighten (3) #15 x 2.5" CTX screws in each bracket.
- 7.** Complete snow fence assembly.