



Address: 2055 S. Raritan
Denver, CO 80223

Toll Free: (877)414-7606
Fax: (720)387-8361

www.rockymountainsnowguards.com

ST11 Retrofit Installation
Instructions for DaVinci
Bellaforté

*Snow Guards for existing synthetic
slate and shake, shake, cedar
shingles and asphalt shingle roofs.*

1. Follow recommended layout pattern for specific roof and snow situation following the Rocky Mountain Snow Guard Layout Guide.
2. There should be at least 6" spacing between the snow guard pad face itself and the butt of the course above.
3. Mark location of each snow guard and apply appropriate sealant.
4. Slide Snow Guard up under product course and press into place.
5. Attach with 2 fasteners (we recommend the Woodbinder Eclipse 10 x 2.5) into strap approximately 1.5" above the pad face.