



Rocky Mountain Snow Guards Inc

ROCKY MOUNTAIN SNOW GUARDS
4231 S. NATCHES COURT, UNIT C
ENGLEWOOD, CO 80110
PHONE: (877) 414-7606
FAX: (720) 387-8361
www.rockymountainsnowguards.com

Blizzard II, Blizzard Heavy Duty II and III Clamp-to-Seam Snow Fence Installation Instructions

Each Blizzard II is comprised of (2) S-5! Mini Clamps pre-attached to a 2-pipe aluminum upright. (Blizzard Heavy Duty II and III are comprised of 2 S-5! Standard Clamps attached to aluminum upright.)


1. Screw stainless steel setscrew(s) into each clamp.

(2 Set Screws on each Blizzard II Bracket)
(4 Set Screws on each Blizzard Heavy Duty II and III Bracket)




2. Using a laser level or chalk line, mark locations for brackets 12" from eave edge.

(1st course only, more snow fence rows may be necessary. Consult Rocky Mountain Snow Guards Snow Retention Plan for location of additional rows.)



3. Tighten each set screw. Torque wrenches are a must to achieve the torque

Torque wrenches are a must to achieve the torque recommended for your specific panel. Recommended torque can be found at www.s-5.com.






Rocky Mountain Snow Guards Inc

Blizzard II, Blizzard Heavy Duty II and III Clamp-to-Seam Snow Fence Installation Instructions Con't)

4. Insert 1" O/D Aluminum Tubing through brackets.



5. Slide Swaged Tube end into un-finished end of adjacent tubes to complete run.



6. Slide End Collars onto tubing and tighten being careful to locate the collars on the INSIDE of the last bracket in a run.

(Collars must be installed to the inside of the last bracket to hold tubing together at joints)



7. Insert End Caps and Attach Ice Flags.

