



Rocky Mountain Snow Guards Inc

ROCKY MOUNTAIN SNOW GUARDS
4231 S. NATCHES COURT, UNIT C
ENGLEWOOD, CO 80110
PHONE: (877) 414-7606
FAX: (720) 387-8361
www.rockymountainsnowguards.com

CorGard Installation Instructions

Low-profile for corrugated steel roofs

1. Acquire layout from Rocky Mountain Snow Guards, Patterns will vary greatly based on a variety of roof factors.
2. Use fasteners that are compatible with the snow guard and roof. We recommend the Woodblinder Eclipse 10 x 2 ½.
3. 1 - Quarter size dollop of sealant that is compatible with the roofing material and the Corgard is to be applied to the top of the panel where the fasteners will penetrate the panel prior to installation of the Corgard.
4. Fasten each snow guard with 2 fasteners and make sure loop is facing DOWN slope with the roof.