



Rocky Mountain Snow Guards Inc

ROCKY MOUNTAIN SNOW GUARDS
4231 S. NATCHES COURT, UNIT C
ENGLEWOOD, CO 80110
PHONE: (877) 414-7606
FAX: (720) 387-8361
www.rockymountainsnowguards.com

L-Bracket Installation Instructions

- 1) Obtain the appropriate fasteners for your particular installation. Contact Rocky Mountain Snow Guards or a structural engineer for recommendations.
- 2) Mark the location of each L-Bracket based on layout recommended by Rocky Mountain Snow Guards. Drift brackets can be installed on top of existing asphalt and metal shingle and metal panel roofs.
- 3) Pre-drill holes through the roof deck and into the supporting structure. Use the L-Bracket base as a template for determining fastener locations. If the bracket base spans 2 courses of asphalt shingles, the tab on the upper course should be removed to provide a flat fastening surface.
- 4) Apply appropriate sealant to the bottom of each L-Bracket. Apply enough sealant for each fastener to be sufficiently sealed.
- 5) Fasten each L-Bracket with the appropriate number and type of fasteners.
- 6) Flash appropriately or seal fastener heads in accordance with compatibility to specific roofing materials.

