

## Rocky Guard Layout Pattern


*For Slate, Shate, Asphalt Shingle, Metal Shingle and Synthetic Slate and Shake Roofs*

### 2) Additional Rows (if required)

Additional rows of Rocky Guards may be necessary to stabilize the snow on longer roof decks, steeper roofs, slippery roof surfaces such as slate, synthetic products and metal and on roofs in heavy snow load areas. Contact Rocky Mountain Snow Guards for a recommended Rocky Guard layout if any of these factors are present.

### 1) Minimum Rocky Guard Eave Row

The row at the eave is the minimum requirement for all roofs. Rocky Guards are spaced approximately 12" O/C and are located on second course of roofing material at or near the load bearing wall.



Note: Roof support structure should always be reviewed to make sure that the additional snow held on the roof will not cause structural issues. On asphalt shingle roofs less than 8/12 pitch where ground snow loads do not exceed 110 psf, additional rows are not required above the eave row.